


Quick Installation Guide


Cloud L2+ Managed Outdoor Gigabit PoE Switch




WI-PCMS310GF-O(V2)

www.wireless-tek.com

1. Packing Content




2. Appearance Overview





LED Indicator&Button	Description
PWR	Off: The device is power off or failed On: The device power on is normal
SYS	Blinking: The Device system is operating normally Off: Device system or power connection abnormality
PoE	On: PoE enabled Off: PoE disabled Blinking: Indicates the port is abnormal
Link	Off: No device is connected to the corresponding port. On: Indicates the link through that port is successfully established Blinking: Indicates that the switch is actively sending or receiving data over that port
Reset	Hold for >5 sec. to restore factory default


3. Device Installation





4. Installation



5. Login WEB UI



6. Cloud Login Switch Configuration



7. Warranty Card

Username	Address
Telephone No.	
Purchase Shop	
Purchase Address	
Purchase Time	
Serial No.	
Dealer Signature	

If the product defects within the warranty period, we will provide professional maintenance service.
 Proof of purchase and a complete product serial number are required to receive any services guaranteed as part of the limited warranty.
 Any other defects that are not caused by workmanship or product quality, such as natural disasters, water damage, extreme thermal or environmental conditions, sticker damaged, warranty card loss will disqualify the product from limited warranty.

Wireless-Tek Technology Limited
 Building 3, Units 1801-1807, 1812,
 Huaqiang Era Plaza, Tangwei Community,
 Fuhai Street, Bao'an District, Shenzhen City,
 Guangdong Province, China.
 Website: www.wireless-tek.com
 Tel: 86-0755-32811290
 Email: sales@wireless-tek.com
 Technical Support: tech@wireless-tek.com

