



# **User Guide**

### **Smart Contact Sensor**

© 2024 TP-Link 1910013756 REV1.1.0

## Contents

About This Guide1
Introduction2
Tapo Smart Ecosystem3
Automate Your Home4
Set Up Your Smart Sensor5
Use Your Smart Sensor8
Explore Smart Actions 10
How to Replace the Battery12
How to Reset Your Smart Sensor
Authentication 14

## **About This Guide**

This guide provides a brief introduction to the Smart Contact Sensor and the Tapo app, as well as regulatory information.

Please note that features available in Tapo may vary by model and software version. Tapo availability may also vary by region. All images, steps, and descriptions in this guide are only examples and may not reflect your actual Tapo experience.

### Conventions

In this guide, the following convention is used:

Convention	Description
Blue	Key information appears in blue, including management page text such as menus, items, buttons and so on.
<u>Underline</u>	Hyperlinks are in blue and underlined. You can click to redirect to a website.


### More Info

- Specifications can be found on the product page at <a href="https://www.tapo.com">https://www.tapo.com</a>.
- Our Technical Support and troubleshooting information can be found at <a href="https://www.tapo.com/support/">https://www.tapo.com/support/</a>.
- The setup videos can be found at https://www.tp-link.com/support/ setup-video/#smart-sensors.

## Introduction


Know when doors/windows are opened or closed. Check on your doors and windows at a glance with the Tapo app and receive instant alerts. This makes your home safer and smarter.

- Real-Time Monitor Monitors the opening & closing of windows, doors, cabinets, the fridge, or the mailbox in real time.
- Instant App Notification Is your parcel locked away? Find out immediately with instant notifications.
- Smart Action Support Connect the actions with other smart devices for a welcome return home.
- Easy Installation Mount to nearly any surface with included 3M adhesive.
- Great Compatibility Just one part of the integrated Tapo ecosystem.
- 2-Year Battery Life Equipped with a CR2032 battery for long-lasting power.
- Device Sharing Easily share management permissions with each member of your family.
- Easy Setup and Use Set up quickly and easily through the free Tapo app.



## Tapo Smart Ecosystem

Tapo is the easy way to turn your home into a smart home. With the Tapo Hub as a bridge, Tapo Smart Sensor works with a wide range of Tapo accessories. So you can easily control and monitor your home from anywhere.



## **Automate Your Home**

Create a Smart Action to automate your smart devices. Customize your own Smart Actions to group your Tapo products together any way you want.





### Light the Way When Arriving Home

Turn on the light automatically when you open the door.





Tapo Hub

### **Build Smart Alarm**

Trigger hub alarm and send you app notifications when someone opens the door or window.



### Secure Door/Window

Your Hub will ring if the door/window is opened.

## Set Up Your Smart Sensor

Watch setup videos at <a href="https://www.tp-link.com/support/download/tapo-t110/">https://www.tp-link.com/support/download/tapo-t110/</a>


#### **Before You Start**

A Tapo Hub is required. Make sure your Tapo Hub is successfully added via the Tapo app.



#### 1. Set Up Your Sensor

Tap the  $\oplus$  button in the Tapo app, tap Sensors, and select your model. Follow the instructions in the Tapo app to complete the setup.



#### 2. Check the LED & Set Up

Check if the LED blinks. If not, use a pin to press and hold the Reset button for 5s. Follow app instructions to complete the setup.

Check the LED Make sure the LED on your device is blinking.
LED is off

#### 3. Test Your Sensor


a. Open and close the sensor to test it in your preferred location.


b. Check the Event Log on the Tapo app to confirm the open/closed status.


#### 4. Mount Your Sensor

a. Stick the included adhesives on the sensor and magnet.

b. Choose where you'd like to install the sensor (but don't attach it yet). Place the magnet near the edge of the door or window that moves.








Notes:

• Leave at least 0.39 inches (10 mm) of space so you can open the battery compartment. • Installation height should not be higher than 6.56 ft (2 m). c. Align the magnet and sensor with no more than **0.59 inches (15 mm)** between them when the door or window is closed. Peel the backing from the adhesive and press the sensor and magnet into place.




## Use Your Smart Sensor

After you successfully set up your hub and sensor, you will see your devices listed on the home page. With the Tapo app, you can view and manage your devices and get instant notifications anytime, anywhere.


#### **Home Page**

This page lists all the devices you've added and you can view them directly and manage them easily. Tap the card to enter its Status page.



#### **Home Page Settings**

Long press on a card, then you can reorder cards, tap 
to remove your device from your account, share your device, favorite/unfavorite device, or relocate your device to other Home.



#### **Status Page**

You can check all events of you sensor. Slide the panel up to check more settings or tap the gear icon to enter the <u>Settings</u> page.

<	0
	Contact Sensor Main Bedroom
Event Log	r
Today	
4:48:23 PM	• Closed
4:48:21 PM	• Opened
4:48:19 PM	• Closed
4:48:18 PM	• Opened
4:11:33 PM	<ul> <li>Closed</li> </ul>
	View All
Smart Actio	ns >
	Den Door/Window Remin then the motion sensor detects

#### **Smart Actions**

The sensor can work with other Tapo devices to automate your home. You can customize smart actions based on the templates.

<	Smart Action	s 🕀
Recommend	ed Involved	
Automation		
Open Door/V Reminder at 2 devices availab	Bedtime	
0 • 4		
Auto Garage 1 devices availat		
	<b>•</b> 0	<b>E</b> ,
Auto Closet 1 devices availab		<b>PT</b> .
	•	
Door Left Open Remine 2 devices availat		ر س

#### **Device Settings**

Check/edit the basic info, set Notifications settings, view User Manual and Placement Guide, or remove your device from your account.

### < **Device Settings** Device Icon Device Name Contact Sensor > Location Main Bedroom > Off > Notifications Smart Actions User Manual Placement Guide Device Info Firmware Update 1.9.0 Build 230704 Rel.154559 Remove

#### **Notifications Settings**

Turn on Notifications if you want to receive app notifications when your sensor detects an event. Set the time you want to be notified.


K Notifications
Notifications
When enabled, you'll receive the notification when an event is detected.
Send Me Notifications
Always
During the Day From 8:00 AM to 8:00 PM
During the Night From 8:00 PM to 8:00 AM
At a Custom Time 🗸
9:00 AM - 6:00 PM >

## **Explore Smart Actions**


The sensor can work with other Tapo devices to automate your home. Trigger different actions when it is opened or closed. You can customize smart actions based on the templates. This makes your home safer and smarter.

#### Option 1: Edit based on the featured actions

1. Go to the Smart Actions page and you will see the Featured Actions (Shortcut or Automation).




2. Tap on a featured action. Select the devices and set the time as needed and tap ADD to save changes.




#### **Option 2: Create your own actions**


1. Go to Smart page. Tap + on the top right to add a simple and smart action.



2. For Shorcuts: Tap + to add action like turning on the smart plug. For Automation: Tap + to add triggers (When) like the trigger time, tap + to add conditions (If) like when the bedroom light is on, and tap + to add actions (Then) like turning on the smart light plug.



<




## How to Replace the Battery

Watch videos at <a href="https://www.tp-link.com/support/download/tapo-t110/">https://www.tp-link.com/support/download/tapo-t110/</a>

If you haven't installed it on a door or window:


Slide to remove the cover.




· If you have installed it on a door or window:

Remove the cover of your sensor by pushing the cover up.

Remove the screw securing the battery and remove the old battery. Insert the new battery into the battery compartment, making sure the battery is level and its positive side is facing up. Then replace the cover.






### How to Reset Your Smart Sensor

Watch videos at <a href="https://www.tp-link.com/support/download/tapo-t110/">https://www.tp-link.com/support/download/tapo-t110/</a>

#### **Option 1. Via Reset Button**

Remove the cover, then use a pin to press and hold the Reset button for 5 seconds until the front LED starts blinking.



### Option 2. Via the Tapo App

Long press the card on the home page and tap  $\bigcirc$  or go to the Device Settings page and tap the Remove button to remove your sensor from your account.

< Device S	ettings		Cancel	1 Device S	elected	Done
Device Icon Device Name	Contact Sensor >		Hubs	•		
Location	Main Bedroom >		Smart Hu	ib 🔾		
Notifications	Off >		Sensors	•	•	•
Smart Actions	>	OR	Contact S Main Bedro		Motion Sen Main Bedroom	0
User Manual	>					
Placement Guide	>					
Device Info	>					
Firmware Update 1.9.0 Build 230704 Rel.15	4559					
Rem	ove		Share			,

## Authentication

FCC Compliance Information Statement

FCC Product Name: Smart Contact Sensor Model Number: Tapo T110 Responsible party: TP-Link USA Corporation Address: 10 Mauchly, Irvine, CA 92618 Website: http://www.tp-link.com/us/ Tel: +1 626 333 0234 Fax: +1 909 527 6804

E-mail: sales.usa@tp-link.com

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.

2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

#### FCC RF Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

"To comply with FCC RF exposure compliance requirements, this grant is applicable to only Mobile Configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter."

We, **TP-Link USA Corporation**, has determined that the equipment shown as above has been shown to comply with the applicable technical standards, FCC part 15. There is no unauthorized change is made in the equipment and the equipment is properly maintained and operated.

Issue Date: 2024-07-23

### **CE Mark Warning**

### CE

This is a class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

#### Operating Frequency / Nominal Operating Frequency / Max Output Power:

863~865MHz / 863.35MHz / 25mW (e.r.p)

863~865MHz / 864.35MHz / 25mW (e.r.p)

868~868.6MHz / 868.35MHz / 25mW (e.r.p)

#### EU declaration of conformity

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2011 /65/EU and (EU) 2015/863.

The original EU declaration of conformity may be found at https://www.tapo.com/en/support/ce/

#### **RF Exposure Information**

This device meets the EU requirements (2014/53/EU Article 3.1a) on the limitation of exposure of the general public to electromagnetic fields by way of health protection.

The device complies with RF specifications when the device used at 20 cm from your body.

Restricted to indoor use.

#### UKCA Mark



### UK Declaration of Conformity

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Regulations 2017.

The original UK declaration of conformity may be found at https://www.tapo.com/support/ukca/

#### Korea Warning Statements:

당해 무선설비는 운용중 전파혼신 가능성이 있음.

#### **NCC** Notice

注意!

取得審驗證明之低功率射頻器材,非經核准,公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。 低功率射頻器材之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。 前述合法通信,指依電信管理法規定作業之無線電通信。

低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。



Продукт сертифіковано згідно с правилами системи УкрСЕПРО на відповідність вимогам нормативних документів та вимогам, що передбачені чинними законодавчими актами України.

#### **Safety Information**

- Keep the device away from water, fire, humidity or hot environments.
- Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us.
- Do not use the device where wireless devices are not allowed.
- Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.
- Do not ingest battery, Chemical Burn Hazard

CAUTION! Risk of explosion if the battery is replaced by an incorrect type

#### CAUTION!

Avoid replacement of a battery with an incorrect type that can defeat a safeguard.

Avoid disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion. Do not leave a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas. Do not leave a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

#### CAUTION: Do not ingest battery. Chemical Burn Hazard

- This product contains a coin / button cell battery. If the coin / button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
- Keep new and used batteries away from children.
- If the battery compartment does not close securely, stop using the product and keep it away from children.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention

#### Warnings

Operating Temperature: 0 °C– 40 °C (32°F–104°F )

Operating Humidity: 10%–90%RH, Non-condensing

Handling Instructions for Lithium Ion Rechargeable Battery

Please read and follow the handling instructions for the battery before use. Improper use of the battery may cause heat, fire explosion, damage or capacity deterioration of the battery.

• Do not place or leave the battery and equipment in the reach of infants so that they are not able to swallow or mistreat the battery by mistake.

In case of ingestion, consult with a doctor immediately.

• Do not let leaked electrolyte come into contact with eyes or skin.

In such a case, immediately wash the area of contact with clean water and seek help from a doctor.

If not treated soon, prolonged contact may cause serious injury.

• Do not put the battery into a fire. Do not use it or leave it in a place near fire, heaters, or high temperature sources.

In such a case, the insulator in the battery may be melted, the safety vent and structure may be damaged, or the electrolyte may catch fire, all of which may cause heat generation, explosion, or fire.

• Do not submerge the battery in water, or wet the battery.

If the protecting device assembled in the battery is damaged, the battery may be charged with an abnormal current and voltage and may cause a chemical reaction within the battery, which may result in the cause of heat generation, explosion, or fire of the battery.

• Do not use any battery charger not specified by the manufacture, also follow the charge conditions specified by the manufacture.

If the battery is charged under other conditions (a high temperature, a high voltage / current, or an altered charger) not specified by the manufacture, the battery may become over-charged with an excessive current and cause heat, explosion, or fire with abnormal chemical reactions.

• Do not use, charge, or leave the battery near fire or in a car under the blazing sun. Such a high temperature may cause damage of the protecting device in the battery, which may result in an abnormal reaction, and then heat generation, explosion, or fire.

• Do not connect the battery reversed in positive (+) and negative (-) terminals in the charger or equipment.

In case the battery is connected and charged reversely, it may cause heat generation, explosion, or fire due to an abnormal chemical reaction.

• Do not let the battery terminals (+ and -) contact a wire or any metal (like a metal necklace or a hairpin) with which it carried or stored together.

In such a case, the battery will be shorted and cause an excessive current, which may result in heat generation, explosion, or fire.

• Do not connect the battery directly to an electric outlet or cigarette heater socket in car.

With a high voltage applied, the battery may overheat, explode, or cause fire.

• Do not throw or drop the battery.

Strong impact may damage the protecting device, which may cause an abnormal chemical reaction during charging and result in heat generation, explosion, or fire of the battery.

• Do not drive a nail in, hit with a hammer, or stamp on the battery.

In such a case, the battery may be deformed and shorted, which may cause heat generation, explosion, or fire of the battery.

• Do not solder the battery directly.

Heat applied during soldering may damage the insulator of the safety vent and mechanism, which may result in heat generation, explosion, or fire of the battery.

• Do not disassemble or alter the battery.

The battery employs a safety mechanism and a protecting device in order to avoid any danger.

If these are damaged, heat, explosion or fire may be caused.

#### CAUTION

• Do not put the battery in a microwave or a pressure cooker.

Sudden heat may damage the seal of the battery and may cause heat generation, explosion, or fire of the battery.

• Do not use the battery with other maker's batteries, different types and / or models of batteries such as dry batteries, nickel-metal hydride batteries, or nickel-cadmium batteries, or new and old lithium ion batteries together.

In such a case, over-discharge during use, or over-charge during charge may occur abnormal chemical reactions and may cause heat generation, explosion, or fire of the battery.

• Do not leave the battery in a charger or equipment if it generates an odor and /or heat, changes color and / or shape, leaks electrolyte, or causes any other abnormality.

In such a case, immediately take the battery out of the charge or equipment and keep it away from fire, otherwise, the battery might overheat, explode, or cause fire.

• Discontinue charging after specified charging time even if the charge is not complete, otherwise, the battery might cause heat generation, explosion, or fire.

• Do not use the battery in the place where the static electricity (more than the limit of the manufacturer's guarantee) occurs. Otherwise, the protecting device in the battery might be damaged and cause heat generation, explosion, or fire.

• Do not use the battery in other than the following conditions; otherwise, the battery might cause heat generation, damage, or deterioration of its performance.

Operating environment:

When the battery is charged:  $0^{\circ}C \sim +45^{\circ}C$  (Humidity < 80%)

When stored 1 months:  $-20^{\circ}$ C ~  $+50^{\circ}$ C (Humidity < 80%)

When stored 3 months:  $-20^{\circ}$ C ~  $+45^{\circ}$ C (Humidity < 80%)

When stored 1 year:  $-20^{\circ}$ C ~  $+20^{\circ}$ C (Humidity < 80%)

Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.

#### Explanation of the symbols on the product label

Symbols may vary from products

Symbol	Explanation
	Class II equipment
	Class II equipment with functional earthing
$\sim$	Alternating current
	DC voltage
\$- <b>@</b> -\$	Polarity of output terminals
	Indoor use only
ţ	Dangerous voltage

Symbol	Explanation
4	Caution, risk of electric shock
VI	Energy efficiency Marking
	Protective earth
<u> </u>	Earth
	Frame or chassis
	Functional earthing
	Caution, hot surface
$\underline{\mathbb{V}}$	Caution
	Operator's manual
$\bigcirc$	Stand-by
	"ON"/"OFF" (push-push)
$\ominus$	Fuse

Symbol	Explanation
	Fuse is used in neutral N
	RECYCLING This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.
Gu	Caution, avoid listening at high volume levels for long periods
	Disconnection, all power plugs
m	Switch of mini-gap construction
μ	Switch of micro-gap construction (for US version) Switch of micro-gap / micro-disconnection construction (for other versions except US)
ε	Switch without contact gap (Semiconductor switching device)