

Quick Installation Guide

Guide d'installation rapide

Guia de Instalação Rápido

Guia de Instalación Rápida

Wireless Router




<http://www.mercusys.com>



For technical support, the user guide and more information, please visit
<http://www.mercusys.com/en/support>.

© 2023 MERCUSYS 7107500299 REV3.2.0

Hardware Connection



*Image may differ from actual product.

English ━━━━

Connect the Hardware

According to the diagram in the opening chapter of this guide, follow the steps to connect the hardware.

If your internet connection is through an Ethernet cable from the wall instead of through a DSL/Cable/Satellite modem, connect the Ethernet cable directly to the router's WAN port, and follow Step 3 to complete the hardware connection.

Step 1: Turn off the modem, and remove the backup battery if it has one.

Step 2: Connect the modem to the WAN port on your router with an Ethernet cable.

Step 3: Turn on the router, and wait for it to start.

Step 4: Turn on the modem.

Configure the Router

1. Connect your computer to the router (Wired or Wireless).

- **Wired:** Turn off the Wi-Fi on your computer and connect your computer to the router's LAN port using an Ethernet cable.

- **Wireless:** Find the product label on the router. Scan the QR code to join the preset network directly, or use the default network names (SSIDs) to join the corresponding network.

Note: Only certain models have QR codes.

2. Launch a web browser and enter <http://mwlogin.net> in the address bar. Create a password for future logins.

Note: If the login window does not appear, please refer to FAQ > Q1.

3. Follow the step-by-step instructions of **Quick Setup** to set up your internet connection and wireless network.

Enjoy the internet!

Note: If you have changed the SSID and wireless password during the configuration, use the new SSID and wireless password to join the wireless network.

MERCUSYS App

The MERCUSYS app provides a simple, intuitive way to access and manage your router. You can block unwelcome devices, set up Parental Controls, configure your wireless settings and more.



Scan the QR code to download the MERCUSYS app from the Apple App Store or Google Play.

FAQ (Frequently Asked Questions)

Q1. What can I do if the login window does not appear?

- Reboot your router and try again.
- If the computer is set to a static IP address, change its settings to obtain an IP address automatically.
- Verify that <http://mwlogin.net> is correctly entered in the web browser.
- Use another web browser and try again.
- Disable and enable the network adapter in use again.

Q2. What can I do if I cannot access the internet?

- Reboot your router and try again.
- For cable modem users, reboot the modem first. If the problem still exists, log in to the web management page of the router to clone MAC address.
- Check if the internet is working properly by connecting a computer directly to the modem via an Ethernet cable. If it is not, contact your internet service provider.
- Open a web browser, enter <http://mwlogin.net> and run the Quick Setup again.

Q3. What can I do if I forgot my wireless network password?

- Connect to the router via a wired or wireless connection. Log in to the web management page of the router to retrieve or reset your password.
- Refer to FAQ > Q4 to reset the router, and then follow the instructions of **Configure the Router**.

Q4. What can I do if I forgot my web management password?

- Log in to the web management page of the router, click **Forgot password**, and then follow the instructions on the page to create a password for future logins.
- With the router powered on, press and hold the **Reset** button on the router for 5 seconds until there is an obvious change in the LED. Wait a few minutes for the resetting and rebooting, and visit <http://mwlogin.net> to create a new login password.

Note: To learn more about the router, please visit our website <http://www.mercusys.com>.

English ━━━━

1

2

Português Brasil ━━━━

Conectando o Hardware

De acordo com o diagrama no capítulo de abertura deste guia, siga as etapas para conectar o hardware.

Caso sua conexão de Internet seja feita através do cabo Ethernet vindo da parede ao invés de um modem DSL/Cabo/Satélite, conecte o cabo Ethernet diretamente à porta WAN do roteador, e siga o Passo 3 para completar a conexão física.

Passo 1: Desligue o modem e remova a bateria, caso houver.

Passo 2: Conecte o modem à porta WAN no seu roteador com um cabo Ethernet.

Passo 3: Ligue o roteador e aguarde por seu reinício.

Passo 4: Ligue o modem.

Configurando o Roteador

1. Conecte seu computador ao roteador (Cabeado ou Wireless).

- **Cabeado:** Desligue o Wi-Fi no seu computador e conecte-o à porta LAN do roteador via cabo Ethernet.

- **Wireless:** Encontre a etiqueta do produto no roteador. Digitalize o QR code para ingressar diretamente na rede predefinida ou use os nomes de rede padrão (SSIDs) para ingressar na rede

correspondente.

Aviso: Apenas alguns modelos possuem QR code.

2. Inicie um navegador web e digite <http://mwlogin.net> na barra de endereço. Crie uma senha para logins futuros.

Aviso: Caso a página de login não apareça, favor consultar FAQ > P1.

3. Siga as instruções passo a passo da **Configuração Rápida** para configurar a sua conexão de Internet e a rede wireless.

Aproveite a Internet!

Aviso: Caso tenha alterado o SSID e a senha wireless durante a configuração, utilize o novo SSID e a senha wireless para acessar a rede Wi-Fi.

App MERCUSYS

O app MERCUSYS oferece um jeito simples e intuitivo de acessar e gerenciar suas configurações wireless e mais.



Acesse o código QR para baixar o app MERCUSYS da Apple App Store ou Google Play.

Português Brasil ━━━━

FAQ (Perguntas Frequentes)

P1. O que fazer caso a janela de login não aparecer?

- Reinicie seu roteador e tente novamente.
- Caso o computador esteja configurado em um endereço IP estático, altere suas configurações para obter um endereço IP automaticamente.
- Verifique se <http://mwlogin.net> está corretamente inserido no navegador.
- Utilize outro navegador e tente novamente.
- Desabilite e habilite o adaptador de rede em uso novamente.

P2. O que fazer caso eu não consiga acessar a Internet?

- Reinicie seu roteador e tente novamente.
- Para usuários de modem a cabo, reinicie o modem primeiro. Se o problema persistir, faça login na página de gerenciamento da web do roteador para clonar o endereço MAC.
- Verifique se a Internet está operando normalmente conectando um computador diretamente ao modem via cabo Ethernet. Caso contrário, contate seu provedor.
- Abra uma janela de navegação, insira <http://mwlogin.net> e inicie a Configuração Rápida.

P3. O que posso fazer se esquecer minha senha de rede sem fio?

- Conecte-se ao roteador através de uma conexão com ou sem fio. Faça login na página de gerenciamento da web do roteador para recuperar ou redefinir sua senha.
- Consulte FAQ > P4 para redefinir o roteador e siga as instruções de **Configure o Roteador**.

P4. O que posso fazer se esquecer minha senha de gerenciamento da web?

- Faça login na página de gerenciamento da web do roteador, clique em Esqueceu a senha e siga as instruções na página para criar uma senha para futuros logins.
- Com o roteador ligado, pressione e segure o botão **Reset** no roteador por 5 segundos até que haja uma mudança óbvia no LED. Aguarde alguns minutos para redefinir e reiniciar e visite <http://mwlogin.net> para criar uma nova senha de login.

Aviso: Para saber mais sobre o roteador, visite nosso site em <http://www.mercusys.com>.

Para informações de aspectos de segurança e adequação do produto no território brasileiro consulte: www.gov.br/anatel/pt-br

