



# **QUICK INSTALLATION GUIDE**


Outdoor LTE/Wi-Fi/GPS/Bluetooth antenna for RUTX11 and RUTM11 routers





#### WHAT'S INSIDE





### **ANTENNA INSTALLATION**
















### **ANTENNA INSTALLATION**
















### **MAST & WALL INSTALLATION**








## **STANDARD POE POWER SUPPLY**



## Teltonika routers support passive PoE only via their LAN1 port



#### Please note:

- Teltonika routers are not compliant with the IEEE 802.3af-2003 standard. Powering one via an IEEE 802.3af-2003 power supply will damage the router due to the this standard's voltage.
- Teltonika routers are not compliant with the IEEE 802.3at standard. They cannot power other devices via Ethernet. They can be powered via any Gigabit passive PoE power supply with a voltage of 9-30 VDC, such as our own power supply:

For power supply, you can use any Gigabit Passive PoE power supply with a voltage of 18-48V in the case of RUTX series routers.

You can use, for example, a power supply from our offer: PR324EUB

Passive PoE power supply is not included in this product.



